

BIGTREE TECH

Eddy V1.0

User Manual



Revision Log

Version	Date	Revisions
v1.00	April 19th, 2024	Initial Version
v1.01	April 25th, 2024	1. Mark the BOOT button's location on the product image. 2. Added instructions for restarting Klipper.
v1.02	April 26th, 2024	Include methods for updating firmware via computer.
v1.03	April 30th, 2024	Revised the configuration and calibration instructions.
v1.04	May 15th, 2024	Indicated the position of the center point.
v1.05	June 6th, 2024	Added the <code>z_virtual_endstop</code> instruction to Section 5.1: Important Notes.

TABLE OF CONTENTS

Revision Log	2
1. Product Information.....	4
2. Feature Highlights	5
3. Product Dimensions and Interfaces.....	6
3.1. Dimension Diagram.....	6
3.2. Instructions for the BOOT Button	7
4. Installation Guide.....	8
4.1. Example using Voron 2.4	8
4.2. Eddy + Manta M5P	9
4.3. Eddy + Manta M8P V2.0	10
4.4. Eddy Coil + EBB36 V1.2.....	10
4.5. Eddy Coil + EBB42 V1.2.....	11
5. Firmware.....	12
5.1. Important Notes.....	12
5.2. Compiling Firmware	12
5.3. Update Firmware via Computer	13
5.4. Update Firmware via DFU	14
5.5. Klipper	16
5.5.1. Configuration for USB Version	16
5.5.2. Configuration for Coil Version.....	17
5.5.3. bed_mesh Configuration	18
5.6. Calibration	19

1. Product Information


Name	Eddy
Weight	6g
Voltage	5V
Static Current	30mA
Operating Current	30mA
Cable Length	2.5 m (USB Version), 15 cm (Coil Version)
Connection	USB: 4-pin, 1.5mm pitch Coil: 4-2.54mm DuPont female header, one end with ZH1 5mm 4P connector
Operating Temperature	≤60°C Ambient
Standard Error	0.5μm
Compatible Models	All FDM printers using the Klipper firmware.

2. Feature Highlights

- Compact size and lightweight;
- Equipped with temperature compensation;
- Highly efficient leveling;
- Broad application, strong compatibility;
- High precision, strong stability;
- Non-contact operation.


3. Product Dimensions and Interfaces

3.1. Dimension Diagram




Note: When installing Eddy, ensure the bottom is at least 1-2 mm above the nozzle.

The coil center point is as follows:



3.2. Instructions for the BOOT Button




Note: Only Eddy V1.0 has the BOOT function; the button on Eddy Coil V1.0 is non-functional.

4. Installation Guide


4.1. Example using Voron 2.4

Installation replaces the original PL-08N position.


Use two M3*25 screws (included in the package) to secure the Eddy to the X Carriage as shown in the diagram.




4.2. Eddy + Manta M5P




4.3. Eddy + Manta M8P V2.0



4.4. Eddy Coil + EBB36 V1.2



4.5. Eddy Coil + EBB42 V1.2



5. Firmware

5.1. Important Notes

1. Klipper has not yet merged the [pull request for fast scanning](#). Until then, please use the BIGTREETECH version of Klipper by running the following commands in your SSH terminal:

```
cd ~/klipper/  
git remote add eddy https://github.com/bigtreetech/klipper  
git fetch eddy  
git checkout eddy/eddy
```

Then, restart the Klipper with:

```
sudo systemctl restart klipper
```

2. When not using the Z endstop, typically, Eddy needs to set the endstop_pin in the [stepper_z] section of printer.cfg to endstop_pin: probe: z_virtual_endstop and comment out position_endstop: 0
3. When Eddy performs temperature compensation, the heated bed temperature can be high. Please be cautious to avoid burns.

5.2. Compiling Firmware

For the USB version, update the firmware of the MCU built into Eddy. For the coil version, update the firmware of the MCU connected to the motherboard.

1. After SSH connects to Raspberry Pi, enter the following in the command line:

```
cd ~/klipper/  
make menuconfig
```

Compile the firmware using the configuration below


```
(Top)
Klipper Firmware Configuration
[*] Enable extra low-level configuration options
  Micro-controller Architecture (Raspberry Pi RP2040) ---->
  Bootloader offset (No bootloader) ---->
  Flash chip (W25Q080 with CLKDIV 2) ---->
  Communication interface (USB) ---->
  USB ids ---->
() GPIO pins to set at micro-controller startup
```

[*] Enable extra low-level configuration options
 Micro-controller Architecture (Raspberry Pi RP2040) ---->
 Bootloader offset (No bootloader) ---->
 Flash chip (W25Q080 with CLKDIV 2) ---->
 Communication interface (USB) ---->
 USB ids ---->

() GPIO pins to set at micro-controller startup

2. After configuring, enter 'q' to exit the configuration interface. When asked to save configuration, select 'Yes'.

3. Enter `make` to compile the firmware. When make is completed, the required `klipper.uf2` firmware will be generated in the `home/pi/klipper/out` folder and can be directly downloaded to the computer on the left side of the SSH software.




5.3. Update Firmware via Computer

1. Press and hold the Boot button, then connect Eddy to your computer's USB port using a USB cable.



2. Once recognized as a storage device, copy the downloaded klipper.uf2 to it. Eddy will automatically update its firmware and restart. The update is complete after the restart.



5.4. Update Firmware via DFU

1. Press and hold the Boot button, then connect Eddy to the USB port of your Raspberry Pi/BIGTREETECH Pi using a USB cable.



2. In the SSH terminal, run the command `lsusb` to query the DFU device ID.

```
pi@fluidpi:~$ lsusb
Bus 001 Device 005: ID 2e8a:0003 Raspberry Pi RP2 Boot
Bus 001 Device 004: ID 1d50:6061 OpenMoko, Inc. Geschwister Schneider CAN adapter
Bus 001 Device 003: ID 0424:0c00 Microchip Technology, Inc. ( formerly SMSC ) SMC9512/9514 Fast Ethernet Adapter

Bus 001 Device 002: ID 0424:9514 Microchip Technology, Inc. ( formerly SMSC ) SMC9514 Hub
Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
pi@fluidpi :~$
```

3. Run:


```
cd ~/klipper
make flash FLASH_DEVICE=2e8a:0003
```

to start writing the firmware (Note: Replace 2e8a:0003 with the actual ID of the device obtained in the previous step).

4. Once firmware writing is complete, run the following to query the ID for USB communication:

```
ls /dev/serial/by-id/*
```

This ID can also be located in Mainsail.



5.5. Klipper

5.5.1. Configuration for USB Version

Configure Eddy in printer.cfg:

```
[mcu eddy]
```

`serial: /dev/serial/by-id/` (Refer to the actual ID found in SSH or Mainsail using the method above)

```
restart_method: command
```

```
[temperature_sensor btt_eddy_mcu]
```

```
sensor_type: temperature_mcu
```


sensor_mcu: eddy

[probe_eddy_current btt_eddy]

sensor_type: Idc1612

z_offset: 1.0 # Set to a non-zero value

i2c_mcu: eddy

i2c_bus: i2c0f

x_offset: 0 # Set actual offset relative to nozzle

y_offset: 20 # Set actual offset relative to nozzle

data_rate: 500

[temperature_probe btt_eddy]

sensor_type: Generic 3950

sensor_pin: eddy:gpio26

horizontal_move_z: 2

[bed_mesh]

horizontal_move_z: 2

Configure other parameters as needed

5.5.2. Configuration for Coil Version

Configure Eddy Coil in printer.cfg:

[probe_eddy_current btt_eddy]

sensor_type: ldc1612

z_offset: 1.0 # Set to a non-zero value

i2c_mcu: EBBCan # MCU name of the actual board connected to Eddy Coil

i2c_bus: i2c3_PB3_PB4 # I2C bus actually connected to Eddy Coil

x_offset: 0 # Set actual offset relative to nozzle

y_offset: 20 # Set actual offset relative to nozzle

data_rate: 500

[bed_mesh]

horizontal_move_z: 2

Configure other parameters as needed

The coil version does not have a built-in thermistor, so there is no need to
configure temperature_probe

5.5.3. bed_mesh Configuration

[bed_mesh]

speed: 50

X and Y movement speed during calibration (mm/s)

horizontal_move_z: 2

Height (in mm) to which the head is moved before starting the scanning
operation

mesh_min: 10, 10

For rectangular beds, defines the minimum X, Y coordinates of the grid. This coordinate is relative to the Eddy's location. This will be the first scanning point, closest to the origin. This parameter must be provided for rectangular beds.

`mesh_max: 220, 220`

For rectangular beds, defines the maximum X, Y coordinates of the grid. Following the same principle as `mesh_min`, but this will be the scanning point farthest from the bed origin. This parameter must be provided for rectangular beds.

`probe_count: 5, 5`

For rectangular beds, this is a pair of comma-separated integers X, Y, defining the number of points probed along each axis. A single value is also valid, in which case the value will be applied to both axes.

Refer to https://www.klipper3d.org/Config_Reference.html#bed_mesh

The parameter `'horizontal_move_z'` in `[bed_mesh]` should be set to 2 to bring Eddy as close to the bed as possible during scanning.

5.6. Calibration

1. After the above configuration is completed, first calibrate the drive current of Eddy. Position Eddy about 20mm above the platform.

Execute in Mainsail's Console:

`LDC_CALIBRATE_DRIVE_CURRENT CHIP=btt_eddy`

Save the settings with `'SAVE_CONFIG'`.

2. Calibrate the relationship between Eddy frequency and Z-axis height. First, home the X and Y axes: `G28 X Y`

Center the nozzle: (ensure there is no height map activated during this step).

`G0 X150 Y150 F6000`

Perform manual z-offset calibration ([Paper test](#)):

`PROBE_EDDY_CURRENT_CALIBRATE CHIP=btt_eddy`

Save the settings with 'SAVE_CONFIG'.

```
09:23 SAVE_CONFIG
```

```
09:23 probe_eddy_current: stddev=144.727 in 3998 queries
      The SAVE_CONFIG command will update the printer config file
      and restart the printer.
```

```
09:22 ACCEPT
```

3. For printers with `z_tilt` or `quad_gantry_level` (QGL) function, run `Z_TILT_ADJUST` or `QUAD_GANTRY_LEVEL` once to prevent the nozzle from hitting the heated bed during grid scanning.
4. At this point, you can home all axes, then execute the following command for rapid grid scanning:

`BED_MESH_CALIBRATE METHOD=scan SCAN_MODE=rapid`

Save the settings with 'SAVE_CONFIG'.

5. Temperature Compensation (The coil version has no temperature compensation, ignore this step):

Note: Exercise caution as the heated bed can reach very high temperatures.

(1) Home all axes.





(2) Set the machine's idle timeout longer to prevent a timeout during the heating process:

`SET_IDLE_TIMEOUT TIMEOUT=36000`

(3) Record Temperatures:

Document the BIGTREETCH Eddy temperature at room temperature.

Set the heated bed to its maximum temperature and a commonly used tool head temperature. Wait for the BIGTREETCH Eddy temperature to stabilize and then record the highest temperature reached, **which will serve as the target temperature for the next steps. Ensure this target is slightly below the maximum to prevent overheating.**

	Extruder	off	25.2°C	0 °C ▾
	Heater Bed	off	25.1°C	0 °C ▾
	Btt Eddy		36.2°C	
	Btt Eddy Mcu		39.2°C	

(4) Wait until it returns to room temperature and then execute:

`PROBE_DRIFT_CALIBRATE PROBE=btt_eddy TARGET=50 STEP=5`

Where TARGET=50 means the target temperature is 50°C, and STEP=5 means each node's temperature scale is 5°C.

For example, if the current temperature is 30°C and the target temperature is 50°C, then the total temperature range is $50-30=20^{\circ}\text{C}$, and the temperature scale for each node is 5°C, so there will be $20 / 5 = 4$ nodes sampled.

Executing the above command will immediately require a manual z-offset calibration ([Paper test](#)). Then manually heat the heated bed and nozzle, waiting for the BIGTREETCH Eddy temperature to rise. The BIGTREETCH Eddy will require another manual z-offset calibration ([Paper test](#)) at the next node, which is 35°C, and then another manual z-offset calibration ([Paper test](#)) at the next node, which is 40°C, and so on.

Should you require further resources for this product, you can find them at [GitHub](<https://github.com/bigtreetech/>). If you cannot find what you need, you may contact our after-sales support (service005@biqu3d.com).

If you encounter any other problems during use or have suggestions or feedback, please contact us. Thank you for choosing BIGTREETECH products.